

January 21, 2009



1 800-234-1982

## Technical Data Sheet

### **Elite Supreme™** Plastic Lens Polish

Elite Supreme provides excellent surface quality and speed for all kinds of plastic lenses. We recommend Elite Supreme for labs needing maximum polishing power. Also, some labs use Elite Supreme as an additive with Elite to increase the overall Baume.

#### **Technical Data**

Baume	25 to 33 Degrees
Average Particle Size	1.5 Microns
pH	3.2 to 4.5

Mix or shake thoroughly to disperse solids. Pour polish full strength into clean polishing machine reservoir or central slurry feed tank. Polishing time will vary depending on type of machine, type of lens, and surface quality of the incoming lens. For best results chill the polish to 60 to 65 degrees F.

Ferro Corporation